

GEAR PUMP ASSY

	
<p>01. SH200A3 K3V153-78213 78MM 2H 13T (安装孔径 78mm 2 孔 13 齿 2 油管/3 油管)</p>	<p>02. DH513 R130 SK100-3/5 K3V153-80413 80MM 4H 13T (安装孔径 80mm 4 孔 13 齿 2 油管/3 油管)</p>
	
<p>03. HD820 HD1023 DH200-5 K3V112 K3V153-90413 90MM 4H 13T (安装孔径 90mm 4 孔 13 齿 2 油管/3 油管)</p>	<p>04. SK200-5 K3V112 K3V154-80413 80MM 4H 13T (安装孔径 80mm 4 孔 13 齿 3 油管/4 油管)</p>
	
<p>05. E200B E180 E240B KP1009C HFSS 51MM (安装孔径 51mm 2 开口 2 油管)</p>	<p>06. E320B E320C E320CU 126-2016 82MM (安装孔径 82mm 2 开口 2 油管)</p>
	
<p>07. E320 E312B E312L 4I-1023 51MM (安装孔径 51mm 2 开口 2 油管)</p>	<p>08. SK100-1/3 SK120-3/5 SK200-1/3 SK100-1/3 KP1009C LFSS 51MM 2H 12T (安装孔径 51mm 2 开口 12 齿 2 油管)</p>

GEAR PUMP ASSY



09. EX30-2 EX35-2



10. EX100-3 EX200-3 ZAX270
4276918 9218005 83MM 10T
(安装孔径 83mm 2 开口 10 齿)



11. EX100-2 EX120-2 EX200-2
4255303 9218004 67MM 2H 10T
(安装孔径 67mm 2 孔 10 齿)



12. EX200-1 EX330-5 ZAX330
4181700 9217993 83MM 2H 10T
(安装孔径 83mm 2 开口 2 孔 10 齿)



13. UH083
4035495



14. 95518-03001



15. SK200-6 SK230-6
K3V154-90413